

## INSTALLATION: V150BAL40E / V150BAL40W

1. Use the template provided to mark the cut-out hole ensuring there are no beams, pipes or cables obstructing the proposed install position.
  2. Use the appropriate hole cutting tool (dependant on wall or eave Material) to cut-out the mounting hole. (fig. 1)
  3. Remove the small safety screw (fig. 2) then detach the Mesh Panel and/or Main Fascia. Place the Vent Body into the cut-out hole and mark the position for the fixing screws. (fig. 3)
  4. Using screws provided (or other type as required) fix the Vent Body securely to the Wall/Eave. (fig. 4)
  5. Attach the Mesh Panel and/or Main Fascia ensuring the Tab has located securely into the notch on the main Vent Body. (fig. 5)
  6. Gently fix safety screw back into position.
- NOTE: Do not over tighten. (fig. 6)

