


Thank you for choosing the award winning Manrose Genius - the leading 100mm intelligent through wall ventilation fan kit. This innovative ventilation product was designed and built in Sweden by a sister company in our group - PAX. The PAX User and Installation Guide, included in the Manrose Genius Kit, is applicable to the Manrose Genius, except for the specific details below. Locate the App by searching for *IEQ Guardian* from compatible android or iOS devices, using Google Play or App Store respectively.

Activate the App

Enter the fan's unique code, found on the right leg of the motor unit shown to the right, to activate the **IEQ Guardian App**.

To remove the motor unit, firmly grip and pull out from the housing. To return the motor unit to the housing, align tabs and click back into position.



Learn more about all the possibilities with our app at www.manrose.co.nz

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.







Assembly through the wall.

- Drill an approx. Ø5 mm governing hole straight through the wall where the fan is to be installed. Then by using the governing hole, use a Ø110 mm hole saw to drill through the wall from both sides.
- Seal the duct joints with moisture-proof tape or sealing compound.
- Place the tube parallel with the wall on the inside. Make sure to keep the outer smaller end to the grill side. Then mark the correct length on the grill side, -25 mm.
- Cut the duct to correct length with a saw.
- Seal the exterior wall grating with sealing compound.
- Assemble the exterior wall grating on the duct. Seal the joints with moisture-proof tape or sealing compound.
- Screw the exterior wall grating to the wall, let the pipe in the wall lean some degrees outward so condensed water can flow to the outside, see Figure H.
- Importantly, Manrose Genius is factory-programmed to work with a continuous basic flow of 30 m³ / h. If continuous basic flow is required, do not install the supplied back draught shutter. Back draught shutter shall only be used when features have been selected where the fan in normal mode is stopped. To set the fan to other functions, download of the Simx Manrose Genius app. is required. See enclosed manual 009-500002 in the fan's packaging.
- When the supplied back draught shutter must be used, be sure to position it as shown in Figure J, then insert the damper in the duct according to figure K.
- Mount the Manrose Genius fan according to the enclosed user and installation guide 009-500002.

Note 1: Cover Plate DCT4375 is an optional accessory for use when retrofitting in the place of larger 150mm fans.

Note 2: When using the App to set up the fan, the reference to *Circuit Breaker* means *Switch* in New Zealand and Australia.

Note 3: Exhaust fans may adversely affect the safe operation of appliances burning gas or other fuels (including those in other rooms) due to back flow of combustion gases. These gases can potentially result in carbon monoxide poisoning. After installation of an exhaust fan such as a partition fan or a duct fan the operation of open flued gas appliances should be tested by a competent person to ensure that back flow of combustion gases does not occur.



Simx Warranty Information



In this warranty:

We means Simx;

You means the consumer of the Goods

Supplier means the authorised distributor or retailer that sold you the Goods in New Zealand or Australia; and

Goods means the Simx product accompanied by this warranty and purchased in New Zealand or Australia.

The benefits provided to you under the following warranty are in addition to any other rights and remedies available to you under the law:

1. If, during the time from the date of purchase (Warranty Period), there is a defect in the Goods due to improper workmanship or material, we will replace or repair the Goods without charge. Any replacement product is warranted only for the time remaining on the original Warranty Period.
2. We are not obliged to replace or repair the Goods under clause 1 if the Goods have been improperly stored, installed, connected, used, operated, repaired, damaged, abused, tampered with, altered (without our written approval), or not maintained in accordance with our recommended installation, connection and operating instructions.
3. We exclude liability for:
 - a) consequential loss or any other loss or damage caused to property or persons arising from any cause whatsoever;
 - b) damage to consumable items such as lamps and starters; and
 - c) damage arising from normal wear and tear.
4. In order to claim under this warranty you must, within the Warranty Period, return the Goods to the Supplier, together with the original proof of purchase including the details below:

Supplier Name _____

Date of Purchase _____

Model Number _____

Invoice/Receipt No. _____

5. This warranty does not cover the cost of claiming under the warranty or transporting the Goods to and from the Supplier.

Our Goods come with guarantees that cannot be excluded under the New Zealand and Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Goods repaired or replaced if the Goods fail to be of acceptable quality and the failure does not amount to a major failure.

To speak to someone about your Simx product or claiming under this warranty, please contact:

Simx Ltd New Zealand

p: +64 9 259 1660 f: +64 9 259 1661

www.simx.co.nz